



WASTEWATER PUMP DRAW DOWN CALCULATOR

Draw Down

Flow meters are becoming more popular in many wastewater applications, but justifying their cost in smaller lift stations and those that are not connected to a SCADA network is often difficult. Some authorities use the “draw down” method as the standard pump test technique. This testing method can be reliable as long as the data collected is accurate and the test is repeated several times to ensure reliability.

Often, a draw down test is used to measure pump flow rate, and then flow rate is used to determine where the pump is running on the H/Q curve. However, flow rate alone may not provide all the needed information. Pressure must also be measured to assess the true performance of the station.

Figure 1 shows the pump curve for a duplex lift station that was designed to pump 400 gallons per minute (gpm) into a gravity main against a static head of 48 feet. The red, horizontal line is the system head at the pump-start level in the wet well. In this example, any friction in the discharge piping will be ignored.

In a standard draw down test, the wet well volume per foot is calculated and the time required to lower the water level one foot is recorded. Dividing the volume by the time in minutes provides us the flow rate in gallons per minute. When possible, we like to use one foot because little change in flow occurs for most pumps over such a small elevation change.

Suppose we perform several draw down tests and compute an average flow of 350 gpm. Based on the performance curve, the pump is operating at 55 feet instead of the design point of 48 feet. Is this reduced flow and increased head due to a blockage in the discharge pipe, or was the original design point incorrect?

It turns out that neither was the culprit. When the pressure was measured at the valve box and corrected for the elevation difference between the water level and the gauge, the operating head was nearly 48 feet. The actual cause of the reduced flow measurement was a leaking check valve that allowed part of the flow to return to the wet well through the other pump. This example is a case that I witnessed in the field and illustrates the importance of measuring both flow and pressure.

The Draw Down Calculator

Figure 2 is a screen shot of the Draw Down Calculator, which is available as an Excel spreadsheet. It provides a standard procedure for testing wastewater pumps when a flow meter is not available. The calculations take into account the elevation difference between the pump start water level and the gauge position.




Engineering Fluid Solutions

Suhaim Bin Hamad Street, PO Box 201401, Al-Muna Bldg., 2nd Floor #5, Doha – Qatar
Tel: +974-44276076, Fax: +974-44376226
www.efsqaatar.com

The calculator also includes the suction and discharge velocity heads in the total dynamic head (TDH) calculation. If the wet well contains submersible or above ground pumps, the wet well volume per foot can be corrected for empty discharge or suction piping in the wet well.

This can increase draw down accuracy in smaller wet wells. Testing wastewater pumps at least twice per year will reveal changes in operating conditions due to changes in system conditions and pump wear. It will also alert end users of potentially damaging off BEP operation.



PUMP CURVE FOR A DUPLEX LIFT STATION

Figure 1


WASTEWATER PUMP DRAW DOWN CALCULATOR

INPUT DATA

Wet Well Diameter (inches)	96.0
Pump Down Distance (inches)	12.0
Pump Down Time (seconds)	40
Discharge Gauge Pressure (PSI)	25.0
Gauge Location to Water Level (inches)	108.0
Pump Suction Diameter (inches)	5.0
Discharge Pipe ID @ Gauge (inches)	4.0
Wet Well Discharge Pipe OD (inches)	5.0
Number of Wet Well Discharge Pipes	2

CALCULATED RESULTS

Wet Well Volume / Foot (Gal)	374
Draw Down Volume (Gal)	374
Flow Rate (GPM)	561
Discharge Velocity @ Gauge (ft/sec)	14.3
Discharge Velocity Head (ft)	3.2
Suction Velocity (ft/sec)	9.2
Suction Velocity Head (ft)	1.3
TDH (ft)	68.6
TDH (PSI)	29.7



Notes

- Enter vertical distance from the Pump On Water Level to discharge gauge location in cell C9.
- Calculations ignore discharge pipe friction since pipe length is usually short. Calculate manually and subtract if necessary.
- Calculations also work for above ground & dry pit pumps.
- For above ground pumps enter the suction piping data in cells c12 & c13
- For dry pit installations enter 0 in cells c12 & c13
- Use a calibrated gauge that reads the measured pressure near the mid point of the gauge range.

Figure 2